



Unit 2, Wharton Street Ind. Est. Nechells BIRMINGHAM B7 5TR Tel: +44 (0) 121 327 7881 Web: landonkingsway.com Email: sales@landonkingsway.com

EMERGENCY PANIC BUTTON



The emergency panic button has a variety of uses where it is required to have a latching push button switch to sound an alarm or isolate equipment. The switch has a normally closed contact which becomes open circuit on the switch being pressed and stays open until the button is reset.



OPERATION

Once pressed the switch latches into position. To reset the switch, twist the serrated section of the knob in a clockwise direction.

If you have any questions or need any help then please contact our sales office.

Technical Specification


Enclosure ABS plastic with red button

Fixing centre: 54 Ø4.3mm
Protection rating IP65 minimum
Switch rating 10A 250Vac
Wire size 2x 2.5mm²
Conduit connection 20mm

Weight 0.1kg

Two screw holes are provided in the base of the unit to allow wall mounting together with cut out recesses allowing for conduit entries.

Electrical connection of the switch should be carried out by competent persons in accordance with the wiring diagram.



INSTALLATION

The switch should be situated in an accessible location and must be clearly marked as an emergency button.

Landon Kingsway part number 10903802
For use with Solenoid Quick-Release, Fire Control Panel, LKGMS and any fire protection system.