

## Free Fall Fire Valve Accessories

10004501. Cable connectors allow cable to be joined



10012402. M6 hook allows cable to be anchored, angled or guided.



100340001P Spring providing tension to cable and free fall fire valve weight through slotted link.



10032902. slotted link allows connection of tensionspring and cable to Free Fall fire valve weight.



10902801. 72°C (160°F) Fusible Link mounted above heat source. Cable will break in the event of fire.



10903610. M6 Large pulley and Wall anchor retains cable tension changing direction of cable.



10030602 M6 Munsen Ring / Wall Anchor.



10903601. BSP Small pulley



10903605. BSP large pulley



LK/10030601 BSP Backplate



99009702 Cable Tensioner



10012102 Warning Notice



# Free Fall Fire Valve Accessories

10033602 ½" to 3" Free Fall Fire valve cable kit



LK/10012401. Brass eye with woodscrew



LK/10903604 Large pulley with woodscrew



LK/LABEL-VALVE Free Fall Fire Valve Lubrication Label



LK/10903756 & LK/10903758 Free Fall Valve Mounting Bracket



10015708 Stainless Steel Cable 9m (29.5ft)



10012101 Mind your head warning notice

